

BETCO Setting Up Your Crewman[™] **AS20B** Autoscrubber

Installation Instructions



Cut and remove black straps from outside of box. Lift and remove box from top of machine.



Remove and discard plastic wrapping.



Remove box containing battery charger, and box containing pad driver assembly.

4



Cut zip tie and remove squeegee assembly.



Use Phillip's head screwdriver to loosen and remove metal brackets.

6



Press and lock pedal on rear right side of machine to lift scrub deck.



Carefully reverse the machine off the back of the pallet.

8



Locate and remove manual in battery housing of machine.



Locate and remove the splash guard from the recovery tank housing. Locate and connect the battery cables.



Install squeegee assembly by aligning at rear of machine and attaching retaining pins.



Place squeegee suction hose into sleeve.



Adjust squeegee to desired height using guide wheel wing nuts.



To install splash skirt, engage metal rings with connector nut, and wrap skirt around scrub deck. Lower scrub deck to the floor with your pad/brush installed and slide skirt down to contact the floor.

14



Lift scrub deck via pedal on rear right of machine.



Press button to activate power to machine.

Center pad driver under scrub deck to engage with machine. Lower scrub deck onto pad driver.

16



Engage pad driver by clicking handle triggers.