


**Daily Routine Maintenance:**

**1** Dust-mop floor.



**2** Fill Autoscrubber using Betco DensiClean at 0.5 oz per gallon. (1:256).



Attach SI Cleaning pad.

*NOTE: Sealant Infused pads are one sided. Be sure to put sealant side down. Pads should be replaced every 200,000 sq/ft.*



Clean entire floor with DensiClean and SI Cleaning pad.



Detail mop corners and edges using Betco DensiClean at 0.5 oz per gallon. (1:256).



**Optional Propane Maintenance:**

**3** Attach SI Burnish pad to propane burnisher.



Burnish entire floor with SI Burnish pad.




Dust-Mop floor after burnishing.




**Stain Removal Procedures:**


**1** Saturate stained area with wet mop and Betco DensiClean at 0.5 oz. per gallon (1:256).




**2** Apply Betco LiquiGrind to fully cover stain and allow to swell 10 minutes.  
250 sq/ft per quart or 1000 sq/ft per gallon.



**3** Attach Betco Honing Tool onto drive plate of swing machine or autoscrubber.  
*NOTE: Machine pad drivers vary. This may require the use of a velcro pad on pad driver.*




**4** Begin Honing Process across entire stained area overlapping 25% on each pass. Pass over stain in this manner a minimum of six to eight passes.  
*NOTE: If using a swing machine to perform this work, 25-40 passes may be required to remove stain/etch.*




**5** Rewet stain area with LiquiGrind if slurry becomes dry or paste like.

**6** Clean and vacuum stained area; if stain is not sufficiently removed repeat process until stain is removed. Clean area with Betco Densiclean at 0.5 oz per gallon (1:256).




**7** Apply Betco Densifier to Honed area, and allow to dry.  
2000 sq. ft. per gallon or 500 sq/ft per quart,


**8** Attach Betco Polishing Tool onto drive plate of swing machine or autoscrubber.  
*Note: Machine pad drivers vary. This may require the use of a velcro pad on pad driver.*




**9** Repeat Step 4 with Polishing Tool.  
*Note: If using a swing machine to perform this work, 25-40 passes may be required to remove stain/etch. Note: This process should leave a white film on the surface when the concrete is sufficiently polished.*




**10** Clean area with auto scrubber and Betco Densiclean solution mixed at 1:256.



**11** Apply Betco Stain Defense and allow to dry.  
1000 sq/ft per quart or 4000 sq/ft per gallon.



**12** "Burnish or Buff" with Betco SI pad to blend area with surrounding floor.



**Betco® Chemical Products**

LiquiGrind	5 gal pail	167005-00
Densifier	5 gal pail	167105-00
Stain Defense	5 gal pail	167205-00
Densiclean	Qts - 12/cs	67912-00
	4 - 2 L Fast Draw	67947-00
*Stain Removal Kit	Qts - 12/cs	92411-00
*6 Qts LiquiGrind, 4 Qts Densifier, 2 Qts Stain Defense		

**Betco® Tooling Products**

Honing tool	3/case	E84133-00
Polishing tool	3/case	E84134-00
Tool holder	3/case	E84130-00
Polishing tool spacer	3/case	E84131-00

**Betco® SI Cleaning Pads**

SI Cleaning Pad, 11"	5 pads/case	E84111-00
SI Cleaning Pad, 12"	5 pads/case	E84112-00
SI Cleaning Pad, 13"	5 pads/case	E84113-00
SI Cleaning Pad, 14"	5 pads/case	E84114-00
SI Cleaning Pad, 15"	5 pads/case	E84115-00
SI Cleaning Pad, 16"	5 pads/case	E84116-00
SI Cleaning Pad, 17"	5 pads/case	E84117-00
SI Cleaning Pad, 20"	5 pads/case	E84120-00
SI Burnishing Pad, 21"	5 pads/case	E84121-00
SI Burnishing Pad, 24"	5 pads/case	E84124-00
SI Burnishing Pad, 27"	2 pads/case	E84127-00



Cleaning Innovations That Matter.